





Contact block symbol  
 X - indicates position contact is closed  
 Y , Z - indicates terminal number

Switch Positions  
 Pos 1 - 208/120v 3ph YY  
 Pos 2 - 240/120v 1 ph ZZ

**LUS5112-10**  
 SCHEMATIC DRAWING  
 MAIN CONTACTS  
 SHEET 2 OF 2  
 8/5/04